## CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

DATE OF ISSUE: 13 March 2017 CERTIFICATE No: 438260



Page 1 of 3

APPROVED SIGNATORY

A Kelly D Pilkington D Whalley C Reed R Armitage



Units 11 - 13 Chorley Central Business Park Stump Lane, Chorley Lancashire PR6 0BL Tel: 0845 2411533 Fax: 0845 2411544

Customer: DJB Labcare Ltd

Address: 20 Howard Way, Interchange Park,

Milton Keynes

MK16 90S

Item Number: 13040342 (4046)

Description: Digital Thermometer

Model/Range: TMD-56

Manufacturer: Amprobe

Date of Cal: 10 Mar 2017

Calibrated by: Luis Combrado

Procedure Name: Amprobe, Digital Thermometer, TMD-56 (DJB Labcare)

03:E-650, Based on BS EN 60584.1 Rev/Basis:

20.0°C ± 2°C <80%rh Temp/Humidity:

The Results on the following pages are: As Found

All Measurements are Traceable to National Standards.

Note 1: The unit under test was calibrated using a multifunction calibrator.

Note 2: Where the reported value lies within the specified tolerances then this will be indicated by the word "PASS", if outside then by the word "FAIL".

Note 3: Values quoted in the "UUT Indicated Value" column are not necessarily quoted to the same resolution as the actual displayed value on the UUT.

Note 4: Any supplied test leads have been checked as part of the Visual/Operational

test but have not been used during calibration.

Note 5: Temperature indicating instruments that contain an internal reference junction for use with thermocouples are calibrated with the reference junction enabled.

Engineers' Notes:

Standard(s) Used: LMMC-02 / LMMC-04 / LMMC-10 / LMMC-14 V

The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k=2, providing a coverage probability of approximately 95%. The uncertainty evaluation has been carried out in accordance with UKAS requirements.

This certificate is issued in accordance with the laboratory accreditation requirements of the United Kingdom Accreditation Service. It provides traceability of measurement to the SI system of units and/or to units of measurement realised at the National Physical Laboratory or other recognised national metrology institutes. This certificate may not be reproduced other than in full, except with the prior written approval of the issuing laboratory.

## CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

UKAS ACCREDITED CALIBRATION LABORATORY No: 0495

CERTIFICATE No: 438260

Page 2 of 3

Parameter	UUT Range	UUT Indicated Value	Applied Value	Acceptanc Low	e Limits High	Pass/ Fail
Visual/Opera Result of						PASS
Measurement	of Thermoo	couples (Electrical S	imulation)			
Channel T1						
Type T		-190.0°C -80.0°C -50.0°C -50.0°C -10.0°C 0.0°C 4.0°C 37.0°C 50.0°C 100.0°C 150.0°C 200.0°C 250.0°C 390.0°C	-190.2 -80.1 -50.1 -30.0 -10.0 0.0 3.9 37.0 50.0 100.1 150.0 200.0 250.0 300.0 390.1	-190.8 -80.3 -50.3 -30.3 -10.3 -0.3 3.7 36.7 49.7 99.7 149.6 199.6 249.6 299.6 389.5 99.3	-189.2 -79.7 -49.7 -29.7 -9.7 0.3 4.3 37.3 50.3 100.3 150.4 200.4 250.4 300.4 390.5 100.7	PASS PASS PASS PASS PASS PASS PASS PASS
Type K		0.0°C 500.0°C 1000.0°C	-0.1 500.0 999.9	-0.3 499.4 999.2	0.3 500.6 1000.8	PASS PASS PASS
Type J  Type E		20.0°C 1100.0°C	20.0	19.7 1099.2	20.3	PASS PASS
Type N		20.0°C 900.0°C	19.8	19.7	20.3	PASS PASS
Type R		20.0°C 1100.0°C	19.9 1100.2	19.6 1099.1	20.4	PASS PASS
Type N		500.0°C 1100.0°C	500.0	497.8	502.3 1102.6	PASS PASS
1150		500.0°C 1100.0°C	500.0	497.8 1097.5	502.3 1102.6	PASS PASS

## CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

UKAS ACCREDITED CALIBRATION LABORATORY No: 0495



Page	3	of	3	
------	---	----	---	--

	UUT	UUT Indicated	Applied	Acceptanc	e Limits	Pass/
Parameter	Range	Value	Value	Low	High	Fail
Channel T2			. 4240	DOW	111911	rall
		-190.0°C -80.0°C -50.0°C -30.0°C -10.0°C 0.0°C 4.0°C 37.0°C 50.0°C 100.0°C	-190.2 -80.1 -50.1 -30.0 -10.1 -0.1 3.9 37.0 50.0 100.1 150.0 200.0	-190.8 -80.3 -50.3 -30.3 -10.3 -0.3 3.7 36.7 49.7 99.7 149.6 199.6	-189.2 -79.7 -49.7 -29.7 -9.7 0.3 4.3 37.3 50.3 100.3 150.4 200.4	PASS PASS PASS PASS PASS PASS PASS PASS
		250.0°C 300.0°C 390.0°C 100.0°F	250.0 300.0 390.1 100.1	249.6 299.6 389.5 99.3	250.4 300.4 390.5 100.7	PASS PASS PASS PASS
Type K		0.0°C 500.0°C 1000.0°C	-0.1 500.0 999.9	-0.3 499.4 999.2	0.3 500.6 1000.8	PASS PASS PASS
Type J		20.0°C 1100.0°C	19.9	19.7 1099.2	20.3	PASS
Type E		20.0°C 900.0°C	19.7	19.7 899.3	20.3	PASS PASS PASS
Type N		20.0°C 1100.0°C	19.9	19.6 1099.1	20.4	PASS PASS
Type R		500.0°C 1100.0°C	500.0	497.8 1097.5	502.3 1102.6	PASS PASS
Type S		500.0°C 1100.0°C	500.0	497.8 1097.5	502.3 1102.6	PASS PASS

End of Calibration Data

Estimated Uncertainty of Measurement:

## Electrical Measurement of Thermocouples

Type:	C E J K K L	+0°C -250°C -210°C -200°C -200°C -200°C +0°C	to to to to to to	+1820°C +2320°C +1000°C +1200°C -250°C +1300°C +900°C +1300°C +1767°C	±(0.64°C) ±(0.48°C) ±(0.53°C) ±(0.30°C) ±(0.66°C) ±(0.32°C) ±(0.31°C) ±(0.40°C) ±(0.61°C)
Type:	S	+0°C		+1767°C	±(0.57°C)
	T	-250°C		-200°C	±(0.69°C)
Type:	T	-200°C			±(0.32°C)