CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

DATE OF ISSUE: 26 March 2018

CERTIFICATE No: 491205







Units 11 - 13 Chorley Central Business Park Stump Lane, Chorley Lancashire PR6 0BL Tel: 0845 2411533 Fax: 0845 2411544

Page 1 of 3 APPROVED SIGNATORY



Customer:

DJB Labcare Ltd

Address:

20 Howard Way, Interchange Park,

Milton Keynes

MK16 9QS

Item Number:

13070037 (4046)

Description:

Digital Thermometer

Model/Range:

TMD-56

Manufacturer:

Amprobe

Date of Cal:

26 Mar 2018

Calibrated by:

Luis Combrado

Procedure Name:

Amprobe, Digital Thermometer, TMD-56 (DJB Labcare)

Rev/Basis:

03:E-650, Based on BS EN 60584.1

Temp/Humidity:

20.0°C ± 2°C <80%rh

The Results on the following pages are: As Found

All Measurements are Traceable to National Standards.

Note 1: The unit under test was calibrated using a multifunction calibrator.

Note 2: Where the reported value lies within the specified tolerances then this will be

indicated by the word "PASS", if outside then by the word "FAIL".

Note 3: Values quoted in the "UUT Indicated Value" column are not necessarily quoted to the same resolution as the actual displayed value on the UUT.

Note 4: Any supplied test leads have been checked as part of the Visual/Operational

test but have not been used during calibration.

Note 5: Temperature indicating instruments that contain an internal reference junction for use with thermocouples are calibrated with the reference junction enabled.

Engineers' Notes:

Standard(s) Used:

Multi-function Calibrator: LMMC-02 / LMMC-04 / LMMC-10 / LMMC-14

The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k=2, providing a coverage probability of approximately 95%. The uncertainty evaluation has been carried out in accordance with UKAS requirements.

This certificate is issued in accordance with the laboratory accreditation requirements of the United Kingdom Accreditation Service. It provides traceability of measurement to the SI system of units and/or to units of measurement realised at the National Physical Laboratory or other recognised national metrology institutes. This certificate may not be reproduced other than in full, except with the prior written approval of the issuing laboratory.

CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

UKAS ACCREDITED CALIBRATION LABORATORY No: 0495

CERTIFICATE No: 491205

Page 2 of 3

Parameter	UUT Range	UUT Indicated Value	Applied Value	Acceptance Low	Limits High	Pass/ Fail			
Visual/Operati Result of Op		aluation				PASS			
Measurement of Thermocouples (Electrical Simulation)									
Channel T1									
Type T		-190.0°C -80.0°C -50.0°C -30.0°C -10.0°C 4.0°C 37.0°C 50.0°C 100.0°C 150.0°C 200.0°C 250.0°C 300.0°C	-190.1 -80.0 -49.9 -29.9 -9.9 0.0 4.0 36.9 49.9 100.0 150.0 200.1 250.0 300.0 390.1	-50.7 -30.3 -10.3 -0.3 3.7 36.7 49.7 99.7 149.6 199.6 249.6 299.6 389.5	-189.2 -79.3 -49.3 -29.7 -9.7 0.3 4.3 37.3 50.3 100.3 150.4 200.4 250.4 300.4 390.5	PASS PASS PASS PASS PASS PASS PASS PASS			
Type K		100.0°F 0.0°C 500.0°C 1000.0°C	0.1 500.0 1000.0	99.3 -0.3 499.4 999.2	100.7 0.3 500.6 1000.8	PASS PASS PASS			
Type J		20.0°C 1100.0°C	20.1	19.7	20.3	PASS PASS			
Type E		20.0°C 900.0°C	19.9	19.7	20.3	PASS PASS			
Type N		20.0°C 1100.0°C	20.1	19.6	20.4	PASS PASS			
Type R		500.0°C 1100.0°C	500.0	497.8	502.3	PASS PASS			
Type S		500.0°C 1100.0°C	500.0	497.8 1097.5	502.3 1102.6	PASS PASS			

CERTIFICATE OF CALIBRATION

ISSUED BY: LAMBDA CALIBRATION LTD

UKAS ACCREDITED CALIBRATION LABORATORY No: 0495

CERTIFICATE No: 491205

Page	3	of	3

	UUT	UUT Indicated	Applied	Accontance	Timita	D/		
Parameter	Range	Value		Acceptance		Pass/		
	Range	value	Value	Low	High	Fail		
Channel T2								
Type T								
		-190.0°C	-189.8	-190.8	-189.2	PASS		
		-80.0°C	-79.9	-80.7	-79.3	PASS		
		-50.0°C	-49.8	-50.7	-49.3	PASS		
		-30.0°C	-29.8	-30.3	-29.7	PASS		
		-10.0°C	-9.8	-10.3	-9.7	PASS		
		0.0°C	0.1	-0.3	0.3	PASS		
		4.0°C	4.1	3.7	4.3	PASS		
		37.0°C	37.0	36.7	37.3	PASS		
		50.0°C	50.0	49.7	50.3	PASS		
		100.0°C	100.1	99.7	100.3	PASS		
		150.0°C	150.0	149.6	150.4	PASS		
		200.0°C	200.1	199.6	200.4	PASS		
		250.0°C	250.0	249.6	250.4	PASS		
		300.0°C	300.0	299.6	300.4	PASS		
		390.0°C	390.1	389.5	390.5	PASS		
Type K		100.0°F	100.0	99.3	100.7	PASS		
Type K	Property of the second	0.0°C	0 1					
		500.0°C	0.1	-0.3	0.3	PASS		
		1000.0°C	500.0	499.4	500.6	PASS		
Type J		1000.0 C	1000.0	999.2	1000.8	PASS		
Type o		20.0°C	20.0	10 7	00 0	77.00		
		1100.0°C	1100.1	19.7	20.3	PASS		
Type E		1100.0 C	1100.1	1099.2	1100.8	PASS		
-11-0 -		20.0°C	20.0	19.7	20.3	PASS		
		900.0°C	900.1	899.3	900.8	PASS		
Type N			300.1	099.5	900.0	PASS		
		20.0°C	20.1	19.6	20.4	PASS		
		1100.0°C	1100.3	1099.1	1101.0	PASS		
Type R					1101.0	LADO		
		500.0°C	500.0	497.8	502.3	PASS		
		1100.0°C	1100.0	1097.5	1102.6	PASS		
Type S								
		500.0°C	500.0	497.8	502.3	PASS		
		1100.0°C	1100.0	1097.5	1102.6	PASS		

End of Calibration Data

Estimated Uncertainty of Measurement:

Electi	rica	al Me	easui	ceme	ent	of	The	ermo	coupl	е
Type:	В	+50	0°C	to	+18	320°	C	± (0	.64°C)
Type:	C		-0°C					± (0	.48°C)
Type:	E	-25	0°C	to	+10	000°	C	±(0	.53°C)
Type:	J		.0°C					± (0	.30°C)
Type:	K		10°C					± (0	.66°C)
Type:	K		10°C					± (0	.32°C)
7 1	L		10°C					± (0	.31°C)
Type:	N		10°C					± (0	.40°C)
Type:	R		0°C						.61°C	,
Type:	S		0°C						.57°C	
Type:	T		0°C						.69°C	
Type:	Τ .	-20	10°C	to	+4	100°	C	± (0,	.32°C)