**ISSUED BY: CALIBRATION MAINTENANCE & REPAIR LTD** 

DATE OF ISSUE: 17 October 2022 CERTIFICATE NUMBER: 1133788





0654



Unit 5 Octavian Way Team Valley Trading Estate Gateshead NE11 0HZ

Tel: +44 (0)191 4875951

Pa	age 1 of 4
Approved Signate	ory
Electronically A	authorised Document
□ P K CLARK □ R J WADE	☐ J FRYER ☐ M FOY
☐ M A FROST  M M S PARDOE	

#### **CUSTOMER**

DJB LABCARE LTD UNIT 12 HOWARD WAY CROMWELL BUSINESS CENTRE NEWPORT PAGNELL BUCKINGHAMSHIRE MK16 9QS UNITED KINGDOM MANUFACTURER STANDARD

DESCRIPTION TACHOMETER OPTICAL

MODEL AT-6

SERIAL No. 200552135

IDENT No. UNKNOWN

DATE RECEIVED 7 OCTOBER 2022

DATE OF CALIBRATION 17 OCTOBER 2022

ORDER No. NS23898

#### **INSTRUMENT CONDITION**

Adjustments Made No Repairs Made No

## **ENVIRONMENT**

The instrument was placed in the Laboratory environment for a minimum period of 4 hours prior to calibration.

The ambient conditions were: 18 to 23°C and 45 %RH ± 15 %RH.

#### **STABILITY**

The results contained in this Certificate refer to the measurements made at the time of test and not to the instrument's ability to maintain calibration.

#### **PROCEDURE**

Measurements were performed in accordance with the in house Laboratory procedure No.1053

The reported expanded uncertainty is based on a standard uncertainty multiplied by a coverage factor k = 2, providing a coverage probability of approximately 95 %. The uncertainty evaluation has been carried out in accordance with UKAS requirements.

ISSUED BY: CALIBRATION MAINTENANCE & REPAIR LTD



CERTIFICATE NUMBER
1133788

Page 2 of 4

UKAS ACCREDITED CALIBRATION LABORATORY No. 0654

<b>Calibration Equipr</b>	Test Equipment			
Cert Number	ldent Number	Model	Serial Number	Calibration Due
M2988	475	A002206.G1	13431078	8 Sept 2023
1132675IH	143	33220A	MY44025316	30 Sept 2023

## Notes:

Results relate only to the items calibrated.

## **Measurement Uncertainties**

These are our best measurement capabilities with the listed test equipment, any uncertainties shown on the result sheet take in to account the resolution of the instrument being calibrated.

Parameter	Range	Uncertainty	Parameter	Range	Uncertainty
Revolutions Per Minute	6RPM to 600RPM	0.064RPM			
	600RPM to 6000I	RPM 0.065RPM			
	6000RPM to 1200	000RPM 0.066RPM			

ISSUED BY: CALIBRATION MAINTENANCE & REPAIR LTD



CERTIFICATE NUMBER 1133788

Page 3 of 4

UKAS ACCREDITED CALIBRATION LABORATORY No. 0654

Parameter

Parameter	Range	Uncertainty	Parameter	Range	Uncertainty
	This p	age is inten	tionally left blank.		

ISSUED BY: CALIBRATION MAINTENANCE & REPAIR LTD



UKAS ACCREDITED CALIBRATION LABORATORY No. 0654

**RESULT SHEET 1053-NC-UKAS: STANDARD AT-6 OPTICAL TACHOMETER** 

# **AS FOUND**

**BATTERY REPLACED: NO** 

The Revolution Per Minute (RPM) was simulated using a precision Frequency Generator with an attached optical light source.

### **RPM**

Range	Simulated	Indicated	Units	Indicated Deviation	Measurement Uncertainty ±
2 to	600.000	600.0	RPM	0.000	0.064
99999RPM	1000.00	1000	RPM	0.00	0.58
	2500.00	2500	RPM	0.00	0.58
	4999.80	5000	RPM	0.20	0.58
	7499.94	7500	RPM	0.06	0.58
	9999.78	10000	RPM	0.22	0.58
	14999.40	15000	RPM	0.60	0.58
	19999.02	20000	RPM	0.98	0.58
	24998.70	25000	RPM	1.30	0.58
	29998.38	30000	RPM	1.62	0.58

Manufacturer stated Accuracy: ±(0.05%+1 digit)

**COMMENTS:** 

TEST ENGINEER: J Fryer DATE: 17th October 2022

Issue No 1 Page 4 of 4